


Power Cable Adapter Connection Diagram

Air-Cooled TIG Torch, One-Piece Power Cable

Air-cooled



! Turn off power before connecting to weld output terminal.